



**SWITCH CONTINUITY**

IGNITION SWITCH		IG	E	HO	BAT
OFF	○	○			
ON			○	○	

ENGINE STOP SWITCH		DIMMER SWITCH			TURN SIGNAL SWITCH			HORN SWITCH	
OFF	ON	Hi	Cl	Lo	R	WR	L	HO	E
OFF	○	○			○			FREE	
RUN		○	○		○			PUSH	
OFF	○	Lo			○				

- B ..... BLACK
- Y ..... YELLOW
- L ..... BLUE
- G ..... GREEN
- r ..... RED
- W ..... WHITE
- Br ..... BROWN
- O ..... ORANGE
- Lb ..... LIGHT BLUE
- Lg ..... LIGHT GREEN
- p ..... PINK
- G ..... GRAY